




Attention Installer



DO NOT OVERTIGHTEN the ball valve swivel nut.

It is recommended to **first hand tighten** the swivel nut, and then **further tighten the nut by a quarter to a third of a turn with a spanner.**



90 – 120 deg
past hand tight